



Philips
Brush

CRP339

Keep your product clean!

Brush to clean your shaver.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense **and** simplicity

Specifications

Replaceable part

- Fits product types:: HQ7405, HQ7415, HQ7615, HQ7616, HQ7617, HQ7814, HQ7815, HQ7816,

HQ7817, HQ7820, HQ7821, HQ7825, HQ7829, HQ7830, HQ7845, HQ7850, HQ7864, HQ7865, HQ7868, HQ7870, HQ7885

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.



Issue date 2011-10-18

Version: 1.0.1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com